

I

PORTARIFIUTI PER RACCOLTA DIFFERENZIATA

EKKO FRONT:

Togliere il coperchio ed i secchi (Fig. 1).

Posizionare la pattumiera a filo del modulo esterno (Fig. 2).

Fissarla alla base (Fig.3) e lateralmente inserendo i 4 distanziatori (Fig.4).

Aprire la pattumiera e fissare lo sportello (Fig. 5) alla foratura prestabilita (Fig.6).

Prodotto con materiali di prima qualità, dalla Ekotech srl - ITALY - I materiali impiegati destinati al contatto delle sostanze alimentari, sono conformi alle prescrizioni contenute nel D.M.31/03/1973 e successive modifiche/integrazioni.



WASTE BIN FOR SEPARATE WASTE

EKKO FRONT:

Remove lid and waste containers (Fig. 1).

Place the frame, (closed), in line with the cabinet door (Fig.2)

Fix the frame in the cabinet and laterally, introducing the 4 supplied spacers (Fig.4).

Pull out the waste bin and fix it to the cabinet door (Fig.5), as the holes on the front frame (Fig.6).

Produced with first quality materials by Ekotech srl - ITALY - The materials used are suitable for contact with foodstuffs, and comply with the regulations in the Ministerial Decree 31/03/1973 and subsequent modifications and integration.



*Is a brand of
Ekotech*

MADE IN ITALY

Modello Depositato
Patent Pending

