

▲ Vorderkante Seitenwand
front edge of side wall

290

64


32

12

16

B

▲ cabinet floor bottom
Schrankboden unten



5

6

7

▲ Doorstrike bottom
Türanschlag unten

▲ Vorderkante
of side wall
front edge of side wall

246

09/2013

VAUTH-SAGEL

ÖKO CENTER 3+4



Montageanleitung / Assembly instructions


ÖKO CENTER 3 ÖKO CENTER 4

44007297_01


▲ front edge of cabinet floor
Vorderkante Schrankboden

A








front edge of cabinet floor
Vorderkante Schrankboden



front edge of side wall
Vorderkante Seitenwand



front edge
of side wall
Vorderkante
Seitenwand



cabinet floor bottom
Schrankboden unten

Doorstrike bottom
Türanschlag unten

