

SALTO


inspired**access**

Nixx.. series


Ⓔ	Signalling	Ⓘ	Segnaletica
Ⓔ	Señalética	Ⓟ	Sinal
Ⓓ	Signalisierung	Ⓢ	Signal
Ⓕ	Signal	Ⓝ	Signal
Ⓝ	Signaal	Ⓕ	Signaalit
Ⓓ	Signalering		



(EN) Acces granted	(IT) Accesso garantito
(ES) Apertura normal	(PT) Acesso autorizado
(DE) Zutritt gewährt	(SV) Tillträde beviljat
(FR) Accès accordé	(NO) Adgang godkjent
(NL) Toegang verleend	(FI) Pääsy sallittu
(DK) Adgang tildelt	




Ⓔ	Access time out	Ⓘ	Limite accesso
Ⓔ	Cierre normal	Ⓟ	Tempo limite acesso
Ⓓ	Zutrittsdauer abgelaufen	Ⓢ	Tillträdestid passerad
Ⓕ	Temps d'accès expiré	Ⓝ	Adgang udløpt
Ⓝ	Toegangstijd verstreken	Ⓕ	Pääsy aikakatkaistiin
Ⓓ	Adgangstid udløbet		





(EN) Access denied
(ES) Rechazo
(DE) Zutritt verweigert
(FR) Accès refusé
(NL) Toegang geweigerd
(DK) Adgang afvist

(IT) Accesso negato
(PT) Acesso negado
(SV) Tillträde nekat
(NO) Adgang nektet
(FI) Pääsy evätty

BEEP  **1 s**
BEEP





(EN) Low battery status	(IT) Status batteria basso
(ES) Pilas bajas	(PT) Status de bateria fraca
(DE) Niedriger Batteriestand	(SV) Låg batteristatus
(FR) Statut pile faible	(NO) Lavt batterinivå
(NL) Laag batterijniveau	(FI) Matala pariston tila
(DK) Lav batteristatus	




(EN) Battery change
(ES) Cambio de pilas
(DE) Batteriewechsel
(FR) Remplacement de la pile
(NL) Batterijwissel
(DK) Batteriskift

(IT) Cambio batterie
(PT) Troca de bateria
(SV) Batteribyte
(NO) Batteribytte
(FI) Pariston vaihto



BEEP  1 s
BEEP
BEEP



SALTO
Recommended
Batteries SP01926-5




- | | |
|-------------------------------|--------------------------------|
| (EN) Office mode notice | (IT) Avviso Modalità ufficio |
| (ES) Puesta en paso | (PT) Aviso de modo office |
| (DE) Office-Modus aktiviert | (SV) Notis om kontorsläge |
| (FR) Notice du Mode Office | (NO) Kontor funksjon aktivert |
| (NL) Loopstand ingeschakeld | (FI) Päiväkäyttötilan ilmoitus |
| (DK) Kontortilstand aktiveret | |



- | | |
|----------------------------|-----------------------------|
| Ⓔ Office mode end | Ⓘ Fine modalità ufficio |
| Ⓔ Fin paso | Ⓘ Fim do modo office |
| Ⓔ Office-Modus deaktiviert | Ⓘ Avsluta kontorsläge |
| Ⓔ Fin du mode office | Ⓘ Kontor funksjon avsluttet |
| Ⓔ Loopstand uitgeschakeld | Ⓘ Päiväkäyttötilan lopetus |
| Ⓔ Kontortilstand afsluttet | |

BEEP  1 s
BEEP



 5 s

(EN) Toogle mode

(ES) Modo toogle

(DE) Mediengesteuerter Modus

(FR) Mode alterné

(NL) Toggle-stand

(DK) Toggle tilstand aktiveret


(IT) Azione

(PT) Alternar

(SV) Toggle

(NO) Veksle

(FI) Tilanvaihto



(EN) Toggle mode end

(ES) Fin modo toogle

(DE) Mediengesteuerter Modus
beendet

(FR) Fin du mode alterné

(NL) Einde Toggle-stand

(DK) Slut på toggle tilstand


(IT) Fine azione

(PT) Terminar o modo alternar


(SV) Avsluta toggle

(NO) Veksle modus avsluttet

(NO) Tilanvaihtu lopetettu



- | | |
|------------------------|----------------------|
| Ⓔ EN Program PPD | Ⓘ IT Programmare PPD |
| Ⓔ ES Programar PPD | Ⓘ PT Programar PPD |
| Ⓔ DE Programmieren PPD | Ⓘ SV Schema PPD |
| Ⓔ FR Programmer PPD | Ⓘ NO Plan PPD |
| Ⓔ NL Programmeren PPD | Ⓘ FI Aikataulu PPD |
| Ⓔ DK Tidsplan PPD | |




(EN) Security error
(ES) Error de seguridad
(DE) Sicherheitsfehler
(FR) Erreur de sécurité
(NL) Beveiligingsfout
(DK) Sikkerhedsfejl

(IT) Errore sicurezza
(PT) Erro de segurança
(SV) Säkerhetsfel
(NO) Sikkerhets feil
(FI) Turvallisuusvirhe



4s



1s

BEEEEEP





226162 -ED. -08/04/2020

All contents current at time of publication.
SALTO Systems S.L. reserves the right to change
availability of any item in this catalog, its design,
construction, and/or materials.